## **CIS for Epson CX5500 Instruction**

Thank you for purchasing AT Continuous Ink Supply System. We appreciate your support and will try our best to make your experience with our products a pleasant one. Printing has been a different experience ever since you installed AT Continuous Ink Supply system on your own printer. Just imagining being able to print without regard to the ink level in those expensive little cartridges.

Please take your time installing AT Continuous Ink Supply system. Do not remove your old cartridge until you have the AT CIS system primed and ready to install (to prevent the drying of heads). In addition, make sure you are getting perfect nozzle checks before installing the AT CIS system. The AT CIS system won't be able to work properly if the nozzles are previously clogged.

Most people get a perfect nozzle check the first time after installing the AT Continuous Ink Supply system; others may need to run two or three cleaning cycles or let the printer sit for a while before they get the perfect results.

### 1. General Guide:

#### 1) Components

- A. CIS system1 setB. Air filters4 pcsC. Support Arm1 set
- D. Refill Kit 4 pcs
- E. Instruction CD 1 pc



#### 2) Opening box inspection

a、Check whether all the accessories are ready.

b. Check whether there's the leakage of the CISS, whether some tubes have been separated from the CISS, whether there are air bubbles in the tube (If there exists more than 20CM air space, please kindly to contact with the local dealer)

## 2. Printer testing:

- 1) Check whether the printer is in normal condition, like mechanical status, lubrication status etc.
- 2) Print testing lines to ensure the printing head is good condition.
- 3) Print pictures to see whether the printing image is ok.

# 3. Installation Procedure

#### **Step 1: Preparation**



Put the CISS on the right side of the printer. and place all the tubes at correct position.



Pull out the small rubber plug from the air hole as picture shown above.



Place 4pcs of air filters into air holes,

#### Step 2: Take out the original cartridges



Press the button to replace cartridges



Move the carriage to the suitable place.



Pull out the power cord, then you can move the carriage.

#### Step 3: Remove the carriage cover



Remove the clip of the cartridge, as the above red rectangle shown.



Take out the original carts.



Use a screwdriver to insert into the joint slightly . Then remove the cartridge cover directly.





Ready to install CIS






Put the original cartridge on the top of the clips Press the original cartridges to the clips. as the red circle showing.






Make sure the two clips lock the original Cartridges.



Make sure the top and bottom pin aim at the two springs.



Push it to the top unit the third clip locks the cartridge.



(1) reset button. (2) switch. If the switch is turned to up place, then CISS should work with original cartridge. If the switch is turned to down palce, then CISS Can work without original cartridge.

#### Step 5: Install Cartridges



Move the carriage to the left-side



Place the CIS cartridge and pipeline though the printer cover as above picture shown



Then move the carriage back to the original place.



Insert the CISS cartridge in the same way as above picture shown



Press those cartridges to make sure it is well installed.



As the red rectangle shown, if all the cartridges are well Installed, you can hear some sound.






Then stick another support arm over the first one.



Stick the short support arm parallelly as the above picture shows.

Stick the support arm in the place as the picture shows.



Clip the tubing.



Make sure the tubing pass through the flute.



Installation is finished.

## Step 7: Adjust tube line



Move the carriage to the leftmost and rightmost to make sure that the tube can be straight.



Installation is finished.





Too long

Twist

Step 8:






Turn on the power and check whether the printer can work.

### Step 9: Check the nozzle





Nozzle is ok

Print test lines. If it is OK, then you can begin using.

	the second se
and the second s	the state of the second division of the secon
	and the second se
the second se	Construction of the Owner where the Party of
and the second se	the second
Concession of the second se	and the second sec

**Broken Lines** 

If there is broken lines, then pls clean the printer head.

Enter Checking Nozzle Panel

Broken lines may be caused by air entering the nozzles. If there is still some broken lines after cleaning printer head repeatedly, especially for single color, then you can leave the printer for about 1 hour. Then the broken lines may disappear. If there is still such problem, then pls contact local dealer.

# 4. Chip Reset



If there is light flashing during printing,

And if there is panel reminding you to change the cartridge, then pls turn off the printer and re-start it after 1 minute. The chip is reset.

Besides, you can reset the ink by pressing the ink-lacking light three times. The procedure is: First, press the button and the cartridge-car moves out and the ink-lacking cartridges are indicated; second, press the button again, the cartridge-car move to the cartridge-changing place. Thirdly, press the button once again after several seconds. Then the printer will default that you change the new cartridges.

Note: If your printer is produced after June 2007, you have to remove the cartridge and install again to reset the Chips.

# 5. Refill in Ink



Please pay attention to the ink level in the reservoirs; if the ink level is below 1CM as the picture shown above, please use refill kits to fill ink into Reservoir bottles. Carefully pull out the rubber plugs from the ink refill holes (There is possibility of ink spattering. Pls be careful.) Refill ink according to the colors. Then re-cap the rubber. (Please keep the printer and the reservoir bottles at the same horizontal line during the process of refilling ink.)

## 6. Attention for Maintenance:

Take out the CISS including the inner cartridges and other components. Then remove support arm from printer, and re-install original cartridges. Please inquire local dealer before sending to maintenance.

#### 7. Notice:

1. Please don't take out cartridge at random after installing the CIS system. Keep the reservoir bottles on the same level with the printer.

- 2. Try to keep at least 1/2 inch of ink in the bottles.
- 3. Don't place the Reservoir Bottles too much higher or lower than the printer.
- 4. Suggested using in a dry place between 15 and 35 degree. Avoid exposure to direct sunlight.

5. Don't reverse or lean the continuous ink supply systems during shipping. Please make sure all the ink filling holes and ventilation holes are closed tightly during transportation. Otherwise, the ink may leak.

- 6. Don't sway the cartridge frequently. It may cause ink leakage.
- 7. Don't pull out the connector of cartridge and don't tear off adhesive tape at the bottom of cartridge.

### 8. Warning:

1. Not drinkable; keep it out reach of children.

- 2. Avoid exposure to direct sunshine and don't keep it in high or freezing temperature.
- 3. Avoid collision and fallen down.